









## Installation Manual
















Model No.: BL101

### Installation Steps



# Installation Manual

Model No.: BL101

Parts list			
No.	ITEM	SPECS	QUANTITY
A			1
B			1
C			1
D			1
E			1
F			1
G		M8*65	4
H		M8	6
I		M8	4
J			1
K		M8	2
L		M4*12	4
M		M4*20	2
N		M4	1
O			1