









## Installation Manual













Model No. : L205

### Installation Steps



# Installation Manual

## Model No. : L205

<b>Parts list</b>			
<b>No.</b>	<b>ITEM</b>	<b>SPECS</b>	<b>QUANTITY</b>
A			1
B			1
C			1
D			2
E		M8*60	4
F		M8Cap	4
G		M8Gasket	4
H		ST4.8*25	4
I		M4*12	8
J		M5	1
K		M4	1
L		M3	1