

Installation Manual



Model No.: BL200

Installation Steps

<p>1</p>	<p>2</p>		
<p>3</p>	<p>4</p>		
<p>5</p> <p>Please mind the arrow direction</p>	<p>6</p>		
<p>7</p>	<p>8</p>		

Installation Manual

Model No.: BL200

Parts list			
No.	ITEM	SPECS	QUANTITY
A			1
B			1
C			2
D			2
E			2
F			1
G		M8*65	4
H		M8	8
I		M8	4
J			2
K		M8	2
L		M4*12	8
M		M4*20	4
N		M4	1
O			1